

Clamptite™ Tool

(97K10.80)



Place wire around handle and through loop.



Wind wire around handle and through loop again.



Remove connector and spread wire ends.



Attach tool as shown, place wire over the front pin and wrap around rear pin. Twist ends together.



Place notch on the end of the tool against the wire loop and tighten wingnut clockwise.



Rotate tool over to lock the wire. Loosen the wingnut and remove the clampite tool.



Clip off and tidy the wire ends.
