veritas®

Optical Center Punch

1. Mark intended drilling location on workpiece.
2. Place base over your mark.
3. Insert optical post into base.
4. Move base until crosshairs line up with your mark.
5. Steady base. Replace optical post with center punch.
6. Strike the center punch.

Optical post may be used alone as an 8x inspection tool.

Veritas Tools Inc.
Ottawa ON K2H 1C2 Canada
veritastools.com
© Veritas Tools Inc. 2018
403 IWE-549_A