

Gutter Siphon

(CA301)

The following instructions were provided by the manufacturer.

This unit is designed to siphon water into the downspout while stopping leaves and other debris from entering. The following guidelines will ensure that the siphon works effectively.

The gutter siphon is not meant to take the place of regular cleaning. Before installation, be sure the eavestrough is free of leaves and debris. In areas that are heavily treed, eavestroughs should be cleaned as often as three times per year.

Be sure the tube is firmly seated in the downspout. The gutter siphon will continue to work, even if it is completely submerged.
