



⚠ Must read before use. Failure to do so can result in serious injury or death.

Vor Gebrauch unbedingt lesen. Andernfalls sind schwere Verletzungen oder Todesfälle möglich. **HIER SCANNEN.**

À lire absolument avant toute utilisation. Le non-respect de cette consigne peut entraîner des blessures graves, voire mortelles. **SCANNER ICI.**

Leer antes de usar. El no hacerlo puede resultar en lesiones graves o muerte. **ESCANEE AQUÍ.**

Lezen voor gebruik. Het nalaten hiervan kan leiden tot serieuze verwondingen of de dood. **SCAN HIER.**

Da leggere prima dell'uso. In caso contrario, possono verificarsi lesioni gravi o morte. **SCANSIONA QUI.**

SCAN HERE



HOW TO USE YOUR SOLO STOVE HANDLE

Step 1

Angle Handle downward as shown and lower into you Solo Stove® fire pit with the larger bumper pointing down. A quick adjustment to the flame ring may be needed.

Step 2

With Handle positioned roughly in the center of the fire pit, insert the shorter bumper's rod through any upper vent hole around the inside of the fire pit.

Step 3

Lift up on Handle to bring the rubber on the larger bumper into contact with the inside wall of the fire pit as shown. Gently lift Handle to carry your fire pit.

Step 4

To remove Handle, gently set your Solo Stove® fire pit down and follow steps in reverse. Some slight downward pressure may be required to disengage Handle.



NOTE

Two people are recommended to use Handle with Yukon & Canyon fire pits.

SAFETY & CARE

NOTE: Two people are recommended to use Handle with Yukon & Canyon fire pits.

- **WARNING** – Do **NOT** attempt to use Handle with a Solo Stove® fire pit that has a fire or burning coals. Allow the fire pit to cool completely before using Handle. Injury to yourself and/or Handle may occur.
- Handle is designed to help lift your Solo Stove® fire pit. It is the responsibility of the user to ensure they are physically capable of this type of activity. A two-person lift is always recommended.
- Only use the Handle model designed for your size Solo Stove® fire pit.
- Handle is not designed to stay in position when let go, only when held.
- Do **NOT** swing your Solo Stove® fire pit while carrying.
- Do **NOT** use Handle to hang your Solo Stove® fire pit or use it in a manner other than shown.
- Do **NOT** pull Handle upwards in quick, jerking motions or Handle may become wedged into position.
- Do **NOT** use Handle to pull your Solo Stove® fire pit out of mud or ice, as this may damage the fire pit and/or Handle.
- When not using Handle, it should be stored in a dry location and out of direct sunlight for long periods of time. Care should be taken to keep dirt and ash out of front and back bumpers.
- If Handle gets wet, make sure to dry completely. Do **NOT** use harsh chemicals to clean Handle.
- Handle is made from stainless steel, but it will slowly patina over time. Slight discoloration is normal and should not be perceived as a defect.

FOR QUESTIONS OR COMMENTS, PLEASE VISIT SOLOSTOVE.COM/CONTACT