



Surround Extend

Instruction Manual



BEFORE YOU BEGIN



Scan for easy 3D instructions
Download the BILT app before you begin



Download on the
App Store

GET IT ON
Google Play

WHAT'S INCLUDED




M6x16mm
Bolt (Qty. 44)



M6x20mm
Bolt (Qty. 8)



Washer (Qty. 52)




Support Bracket (Qty. 4)



Riser (Qty. 4)



Table Leg (Qty. 4)



Crossmember Support
(Qty. 4)






Table Panel (Qty. 4)

ASSEMBLY **Before Assembly:** Remove all items and pieces from their packaging and wrapping. Place a cardboard box or outdoor blanket underneath the pieces to prevent any scratching of the powder-coated surface.




Step 1: Remove the Surround Bezel and then your fire pit from the Surround. Place your Surround in preferred location outside, ensure that area is level for more desirable results.




Step 2: Place one Surround Extend riser piece under each leg of the Surround, the bolt holes on the risers must be facing left.

Once all four risers have been placed under the Surround legs, adjust the foot levelers to the appropriate height to avoid rocking.




Step 3: Remove the outer two (2) bolts and washers from the underside of the Surround table support brackets. Loosen the two (2) inner bolts from the same Surround table support bracket.




Step 4: Align the Surround Extend support bracket with the Surround shelf support bracket. Use two (2) 20mm bolts and two (2) washers to fasten the Surround Extend bracket to the shelf support.


Tighten the inner and outer bolts on the shelf support.




Repeat steps 3 and 4 for the remaining three (3) brackets.




Step 5: Lay one table panel upside down on a soft surface. (NOTE: Do not complete this step on a hard surface such as brick, concrete, or pavers. This could scratch the surface.) Align table leg with the table panel underside, and fasten completely with three (3) 16mm bolts and washers.



Repeat Step 5 for the remaining three (3) table panel sections




Step 6: Flip the assembled piece, and align it with the recently attached Surround Extend brackets.




Step 7: Hand thread four (4) 16mm bolts and washers to attach each table panel section to the brackets. Once all four table panel sections are assembled, tighten bolts with the supplied wrench.

Repeat Steps 6 & 7 for the remaining three (3) table panel sections.




Step 8: Align the crossmember support between the assembled Surround Extend riser piece and the table leg bolt holes.



Step 9: Use four (4) 16mm bolts and washers to fasten the crossmember to the riser and table leg.

Repeat Steps 8 & 9 for the remaining three (3) crossmembers.



Step 10: Adjust the leg levelers as needed per your preference.

USAGE & WARNINGS

IMPORTANT SAFETY WARNINGS. KEEP THESE INSTRUCTIONS FOR FUTURE USE. DO NOT DISPOSE OF THIS MANUAL.

Read instructions in full prior to assembling and using the Solo Stove Surround Extend.

It is the responsibility of the Owner to ensure that all people in the vicinity of the Surround Extend and Fire Pits are aware of the warnings and precautions while the unit is in use. Use extreme caution and common sense when operating or near the Surround Extend. Failure to do so could result in severe bodily injury or property damage.

WARNING: Failure to comply with all the Manual provisions and usage guidelines could result in property damage, serious bodily injury, death, or fire. Solo Stove does not accept any responsibility, legal or otherwise, for the incidental or consequential damage to property or persons resulting from the misuse of this product.

Solo Stove shall in no event be liable for any special, indirect, consequential, or other damages of any nature whatsoever in excess of the original purchase price.

• FOR OUTDOOR USE ONLY

- Use only with the appropriately sized Solo Stove Fire Pit and Surround (SMALL for the Ranger and Bonfire. LARGE for the Yukon and Canyon Fire Pits.). Follow all fire pit guidelines and instructions when using with the Surround Extend.
- Do NOT leave children or pets unattended around the Surround Extend when the fire pit is in use or cooling down.
- Exercise caution when using your Surround Extend or serious risk of death or injury may result.
- Surround Extend and fire pit areas will be hot. Do NOT sit on or lean against Surround Extend.
- Install on level, stable surfaces only. Do NOT use the Surround Extend on inclined surfaces, uneven ground, vehicles, boats, stairs, or surfaces not designed to handle the weight of the Surround Extend and fire pit.
- Do NOT attempt to use the Fire Pit Stand with a fire pit in the Surround. The Surround is designed so that the fire pit will rest directly onto the fire pit supports on the Surround crossmembers. No Fire Pit Stand is needed.
- Do NOT modify or alter the Surround Extend or use in a manner other than specified.
- Do NOT attempt to move the Surround with a fire pit installed. Remove fire pits from the Surround Extend prior to moving.
- Do NOT attempt to move a Surround Extend or remove a fire pit from a Surround Extend while a fire is going or while a fire pit is cooling down.
- Do NOT set plastics or heat sensitive materials on the Surround Extend table panels while in use.

- The powder coated finish is very durable, but it can be scratched. Do not drag items across the table panels to avoid damaging the surface.
- Take care to avoid dropping logs or other items onto the table panels or damage could occur.
- Keep the Surround Extend from sitting in standing water or prolonged periods covered with Snow and/or Ice.

Remove all items from box, carefully unwrap, and inspect for damage. During assembly, do not place items on abrasive or rough surfaces or damage to part finish may occur.

If any parts are damaged or missing STOP and contact Solo Stove Customer Service at (817) 900-2664