


pi Lazy PiZolo



SETUP



Place the Lazy PiZolo on a flat, level, non-combustible surface, or on the Pi Stand shelf. Make sure that it is in the locked position, with one of the Solo Stove logos facing you.



While the Pi Pizza Oven is cool, position it on the Lazy PiZolo by matching the Pi's four (4) feet into the recessed indices on the PiZolo.



Give the Lazy PiZolo a gentle spin. It should rotate smoothly and easily. There are detents every 180° which will stop the oven at the correct position for adding wood and launching pizzas.

- If there's any resistance or wobble, double-check that both the Lazy PiZolo and your Pi Pizza Oven are properly centered and level.
- Always spin the Pizza Oven slowly and deliberately.
- Time to cook up some delicious wood-fired feasts!

WARNINGS

- For use with Solo Stove Pi wood-burning setup only.
- Do not attempt to use the Lazy PiZolo when using the gas burner.
- Always place the Lazy PiZolo on a flat, level, sturdy surface.
- Not to be used by children.
- Exercise caution while using when Pi is hot.

- Do not spin too quickly or more than 180° at a time.
- Do not submerge in water. Use a damp towel, soap, and water to clean. Dry all elements of the Lazy PiZolo immediately.
- For a full list of pizza oven warnings, please review the Solo Stove Pi Pizza Oven instruction manual.



 solo stove®