


Landing Zone Requirements

Preferred landing areas include:

- Parking lots
- Paved roads
- Unplowed fields without animals nearby
- Upwind from hazmat/fires

Minimal landing area:



Landing lights:

From dusk to dawn, place landing lights at each corner of the landing area.

During daylight hours, place orange cones at each corner.

Avoid: ▪ Caution tape ▪ Flares

Radio Communications

Aero Med Radio Frequency:

155.400 PL 35 (179.9)

AIR LZ 1 (800 MHz)

Alternate Radio Frequencies:

DNR Freq: 154.295

- Provide location/description of landing zone
 - Obstructions to look for and report:
 - Trees
 - Poles
 - Wires
 - Cell Towers
 - Buildings
 - Signs
 - Surface condition (rocks/slope)
 - Wind direction
-

Aero Med will contact you when we are **five minutes** from the scene.

If you are unable to communicate with the aircraft:

Call Flight Communications Direct

1-800.862.0921

Attempt to relay information through dispatch. During daytime hours, the aircraft may land without communication and use visual clues from the landing zone coordinator.