



Roku®

Pro Series TV



Let's get started


What's included



Roku 4K OLED TV




Roku TV Remote



TV power
cord

x 4
Thumbscrews



x 2 TV stands with
cable management clips

Need help?

For setup help or support, visit or call

go.roku.com/TV


1-816-272-8106

4:00 am – 10:00 pm PT



For mounting instructions,
visit **go.roku.com/TVmount**

STEP 1: Attach stands



A Prepare a surface


Put a soft covering like a blanket down onto a clean, flat surface (make sure it's larger than the TV) and place the TV on it.

B Attach the stands

Slide stand into slots and secure with included thumbscrews. Set TV upright on a stable, flat surface.

Note: Stands are adjustable. Choose from two different heights.

STEP 2: Plug TV in and power your remote



A Connect your TV

Plug your TV into a power outlet. It should turn on automatically. If it doesn't, press the power button.

B Power your remote

See the remote features card on how to use your Roku TV remote.

STEP 3: Activate your TV



Follow on-screen setup

Note: You'll need a internet connection and a Roku Account to activate your TV.

IMPORTANT

Roku never charges for activation support.

Get to know your TV

Video connections

-  **HDMI 1 & 2** – General video input
-  **HDMI 3 & 4** – Game consoles
-  **Antenna/Cable** – Digital antenna, cable connection

Audio connections

-  **HDMI 1 eARC (recommended)** – AV receivers, soundbars
-  **Optical** – AV receivers, soundbars


Other connections

-  **USB** – Flash drive for media playback
-  **Ethernet** – Wired internet connection

Lost remote finder button

-  **Can't find your remote?** Your TV can help with this button.

Cable management clips



Use the clips on your TV's stands to keep things tidy.



© 2026 Roku, Inc. All Rights Reserved. Roku, the Roku logo, and the purple d-pad and purple fabric tag designs are trademarks or registered trademarks of Roku, Inc.

Dolby, Dolby Vision, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories.
Confidential unpublished works. Copyright © 2012–2024 Dolby Laboratories. All rights reserved.