

SAFETY NOTICE

EcoBoulder Bluetooth Speaker by ECOXGEAR



EcoBoulder

Model # GDI-ECBM900 series

UPC Code 81927010348



Hazard: The speaker's battery can become overcharged, and burst, posing fragmentation and impact hazards. Consumers should immediately stop using the speaker and contact ECOXGEAR customer service for a free battery replacement kit.

ECOXGEAR Customer Support

800-903-9664 | 8 a.m. to 8 p.m. CT | Monday through Friday

www.ecoxgear.com/safetynotice