



Parts List

Index	Part No.	Description
1	4530B-1	INSTALLATION FORCING SCREW
2	4530B-2	HEX HEAD INSTALLATION SCREW
3	4530B-3	GM PUMP STYLE PULLEY REMOVAL SCREW
4	4530B-4	PUMP/ALTERNATOR PULLEY REMOVER
5	4530B-5	PULLER COLLAR HALVES
6	4530B-6	COLLAR RETAINING RING