


MG200SP - MULTIMIG AC/DC WELDER



#	PART NO.	DESCRIPTION	#	PART NO.	DESCRIPTION
1	520.3010	HANDLE - MACHINE	28	521.0321	FRAME - FRONT 200-P
2	521.0380	CABINET - COVER 200-P	29	521.0322	COVER PLATE - ADAPTOR 200-F
3	521.0361	CABINET - DOOR 200-P	30	521.2543	EURO SOCKET FLANGE
4	538.0017	LATCH WIRE FEED DOOR	31	520.3021	WIRE GUIDE
5	521.0362	CABINET - HINGE MOUNT	32	520.3022	EURO SOCKET MOUNT TUBE
6	707.0152	GAS HOSE FITTING "T"	33	511N0015	DINSE PLUG 3550
7	521.2523	GAS SOLENOID VALVE (2)	34	293N0009	HOSE NIPPLE
8	521.0310	PCB POWER BOARD 200-P	35	520.3023	CENTRAL ADAPTOR
9	521.0311	PCB CONTROL BOARD 200-P	36	511N0016	DINSE SOCKET 3550
10	000N0016	HEX NUT STANDOFF	37	521.2526	GAS FITTING 5/8-18
11	707.0162	INSULATOR BUMPER	38	521.0011	SOCKET 9-PIN CONTROL
12	175.9053	CABLE GROMMET	39	520.3027	KNOB - FRONT PANEL
13	521.0363	CABINET - PCB MOUNT	40	521.0314	FRONT PANEL CLEAR COVER
14	521.2526	GAS FITTING 5/8-18	41	521.0312	LCD DISPLAY 200-P
15	707.0175	CORD STRAIN RELIEF	42	521.0313	PCB FRONT PANEL 200-P
16	530.0020	SWITCH - POWER	43	521.0315	FRONT PANEL BACK COVER
17	521.0319	COVER PLATE - REAR 200-P	44	521.0323	INDUCTANCE COIL
18	521.0320	FRAME REAR 200-P	45	521.0324	TRANSFORMER 200-P
19	521.2525	FAN MOUNT PLATE 200-P	46	521.0325	INDUCTANCE COIL
20	521.2524	FAN COOLING	47	521.0326	HALL CURRENT SENSOR
21	521.0364	CABINET - CENTER 200-P	48	521.0327	PFC INDUCTANCE
22	521.2540	SPOOL HOLDER MOUNT PLATE	49	521.0366	CABINET - PCB MOUNT
23	521.2513	SPOOL HOLDER	50	521.0367	COOLING CHANNEL COVER
24	520.3018	WIRE FEED INSULATOR	51	521.0316	PCB AC/DC INVERTER MUR
25	520.3019	WIRE FEED DRIVE	52	521.0317	PCB AC/DC INVERTER PRIMARY
26	521.0365	CABINET - BASE PLATE	53	521.0318	PCB RF CONTROL
27	521.3020	COVER PLATE- WIRE FEED DRI	54	520.0009	GAS HOSE 5/8-18

Item: MG200SP

Description: MULTIMIG AC/DC WELDER

Notes: N/A

Figure No	Part Number	Description	No. Reqd	Warranty Code
-----------	-------------	-------------	----------	---------------