





DATE: June 29, 2021
 SKU NUMBER: AG_BB_HFW04_2B70
 SKU NAME: Bitty's™ Let's Go Potty Set
 AGILE NUMBER: 1101575113_Instruction
 LANGUAGE CODE: 2LB (ENGLISH / FRENCH)
 TYPE OF APPLICATION: Printing
 NOTES:
 SIZE: 9" X 4.5" folded to 4.5" X 4.5"
 TYPE OF FOLD: 2 panel
 MATERIAL: 128gsm BSC
 COLOR: 1C + 1C (Blk)
 COATING: 2/S Waterbase

This is a battery-operated product.
Battery Safety Information and WEEE Logo
 Flyer is required to be placed inside the packaging
 32L 00001-2908-G1

The FCC Flyer is required to be placed inside the packaging.
00007-1849G8



Bitty's™ Let's Go Potty Set
Allons-y, ensemble de siège d'aisances d'enfant de Bitty's

Contains

- 1 potty chair
- 1 pair of training pants
- 1 book

Contient

- 1 siège d'aisances d'enfant
- 1 paire de pantalons d'entraînement
- 1 livre

Tool required for battery installation: Phillips screwdriver (not included).
 Requires 2 AA [LR6] x 1.5V alkaline batteries (not included).
 Dispose of batteries safely.

Outils requis pour l'installation des piles : tournevis cruciforme (non fourni).
 Fonctionne avec 2 piles alcalines AA [LR6] x 1.5V (non fournies).
 Jeter les piles usées dans un conteneur réservé à cet usage.

Keep these instructions for future reference as they contain important information.
 Ces instructions contiennent des informations importantes. Conservez-les pour pouvoir vous y reporter ultérieurement, si nécessaire.




4 Rear

1 Cover

BATTERY REPLACEMENT • REMPLACEMENT DES PILES

- Unscrew and remove the battery cover.
 - Insert batteries as shown on the inside of the battery compartment.
 - Replace the battery cover and tighten the screw.
- Dévissez le couvercle du compartiment des piles et retirez-le.
 - Insérez les piles conformément aux indications fournies à l'intérieur du compartiment des piles.
 - Remplacez le couvercle du compartiment et vissez-le.



For longer life use alkaline batteries.
 Check the batteries installation if product malfunctions.
 When exposed to an electrostatic source, the product may malfunction. Turn the switch off and then power on again.
 HINT: When sounds from this toy become faint or stop, it's time for an adult to change the batteries.
 Note: The product is equipped with an automatic shut-off feature that helps preserve battery life.

Pour une plus longue durée de vie, utilisez des piles alcalines.
 En cas de dysfonctionnement du produit, vérifiez le positionnement des piles.
 L'exposition du produit à une source électrostatique peut provoquer son dysfonctionnement. Éteignez le produit à l'aide du commutateur marche / arrêt et rallumez-le.
 Conseil : lorsque le son émis par le jouet s'affaiblit ou cesse de fonctionner, un adulte doit changer les piles.
 Remarque : la produit est équipée d'une fonction d'arrêt automatique qui permet de préserver la durée de vie de la pile.



2 Rear

3 Rear