

Operating Manual

P8420

Rechargeable Hand Warmer

Thank you for purchasing the P8420 Rechargeable Hand Warmer. If your hands and fingers feel icy whether you're indoors or out, then our Hand Warmer is for you. Slim and lightweight, you can carry it with you anywhere you need a convenient source of soothing heat. This unit will provide you with years of service if cared for properly. Please read these operating instructions thoroughly before use.

How to Use:

- **Charging the Warmer**

1. Plug the USB cable into a computer or USB socket AC/Car Adapter to begin charging. A Red LED lamp will light up above the "Charging" symbol on the unit.
2. When the Hand Warmer is finished charging, the Red LED lamp will turn Green.

- **Use**

1. Press the ON/OFF button to start heating the Hand Warmer; a Green LED lamp will light up above the "Warming" symbol.
2. When the Hand Warmer has reached 106°F (41.1°C) the warming LED lamp will turn off and stop heating. If the temperature of the unit falls below 106°F (41.1°C) the Green warming LED lamp will light up and begin reheating the unit.
3. When the Hand Warmer is low in power, the warming LED lamp will turn Red indicating the user to recharge the unit.
4. To turn the Hand Warmer off, press the ON/OFF button. The warming LED lamp will shut off.

- **Note**

When in use, it is normal for some areas of the housing to be warmer than others.

- **Caution**

1. Charge the Hand Warmer fully before first use.
2. **DO NOT** drop, disassemble or attempt to repair the Hand Warmer yourself.
3. Avoid exposure to water, high humidity, or any heat source.

Specifications:

Model:	P8420
Power Supply:	Rechargeable by mini USB port (5v/600mAh Max Input)
Built-in Battery:	Lithium-ion Battery
Charging Time:	1 ½ - 2 ½ Hours

Warm up Time: 4-5 Minutes
Duration: up to 3 Hours
Temperature: 106°F (41.1°C) max.
Dimensions: 3 5/8" x 1 5/8" x 3/8" (90x40x8.5 mm)
Weight: 1.6 oz.
Contents of Box: Hand Warmer unit, USB charging cable, and a Knit Sleeve case.

*Specifications subject to change without notice.

P3 INTERNATIONAL CORPORATION LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If you experience difficulty in the operation of your unit, or if your unit requires repair please contact:

P3 INTERNATIONAL CORPORATION
TECHNICAL SUPPORT

Tel: 212-741-7289

Fax: 212-741-2288

Email: techsupport@p3international.com

Rev. 0914