

Crown Molding Hanger

(03K18.05)

The following instructions were supplied by the manufacturer.

DO-IT-YOURSELF CROWN MOULDING INSTALLATION TOOL

1. Measure wall where crown moulding will be installed.
2. Cut crown moulding to length.
3. Install multipurpose holders - for wall length up to 12' use 2 hangers, for over 12' use 3 hangers to properly support crown moulding.
 - a) Hangers should be placed so crown moulding is supported equally, for example using 2 hangers place them 1/3 of the way in from each end.
 - b) Install a 1-1/4" roofing nail, 1" from the ceiling, leaving nail head 1/4" out from the wall.
 - c) Place multipurpose holder on nail.
4. Place moulding on multipurpose holder.
5. Loosen nut and tighten moulding to ceiling (hang on to nut and push up on bracket).
6. Check before installation.
7. Attach crown moulding using finishing nails (or power nailer).
8. When you are within two feet of the multipurpose holder loosen the nut and remove the holder (leaving roofing nail behind the moulding).